Touch Screen v4
Change PLC
Time Clock

Tech Guide

WASHLINK SYSTEMS
v4 Touch Screen Change
PLC Time Clock

This document provides comprehensive information for changing the PLC Time Clock from your v4 Touch Screen.

When emailing or calling for assistance, you must have the following information available:

Location Name: _____

Contact Person: _____

Contact Phone: _____

Touch Screen version: _____

Touch Screen S/N: _____

Distributor Name: _____

1. **From the Main Standard or Main Stacker Screen, press OTHER**

2. After reading warning message, press **OK**
3. Press **ADMIN SETTINGS**

4. Press the **box** below ENTER ADMINISTRATOR PASSWORD
5. Number pad will pop up, Enter ADMINISTRATOR Password and press **Enter**
6. Press **SYSTEM SETTINGS**

V4.2.9 and below

7.

FUNCTION SET UP	COLLISION AVOIDANCE	PACKAGE SET UP	SET TIME/DATE
CONVEYOR SET UP	WET DOWN SET UP	OPTION SET UP	MISC. SETTINGS
ROLLER SET UP	TIRE SW SET UP	HOURS OF OPERATION	STACKER SETTINGS
START UP CONFIG	ENTER CONFIG	OVERRIDE CODES	CHANGE PASSWORD

DONE

V4.4.1 and above

7.

FUNCTION SET UP	COLLISION AVOIDANCE	PACKAGE SET UP	TIME/DATE
		OPTION SET UP	MISC SETTINGS
CONVEYOR SET UP	WET DOWN SET UP	PKG/OPT BUTTONS	LANGUAGE
ROLLER SET UP	TIRE SW SET UP	HOURS OF OPERATION	STACKER SETTINGS
START UP CONFIG	ENTER CONFIG	OVERRIDE CODES	CHANGE PASSWORD

DONE

7. Press SET TIME/DATE or TIME/DATE

8. Press the field you want to change and when the keypad pops up, enter the new value and press ENT
9. When ready to set new date & time, put a 2 in the Accept Change box and press ENT
10. Press **Done** to get back to Admin Settings